



Shock Module

Part of the Zombie Management System

Your Shock Module can be plugged in using the provided 5 volt power adapter or by using a standard Micro USB cable and a phone charger. When plugged in, the Shock Module will let off a brief test fire.

To trigger the Shock Module hold down the button for 1 second on the remote that was sent with your device. It has already been paired to the Shock Module.

To Reprogram the Remote:

Turn off any devices – up to 20 - you wish to pair with the remote and then turn them back on. They will be available to be paired for 5 minutes. Hold down the button on the remote for 45 seconds. Hit the remote button again to verify that it worked correctly.

To Use the Remote with Other Trigger Mechanisms:

The remote can be fired with an external trigger. First, loosen the set screws located on the front of the remote, above the trigger. Next, insert your relay lines into the two holes on the topside of the remote and tighten down the set screws.

- Do not use if broken
- Do not use in the rain
- Do not let the unit get wet
- Do not put anything behind the plastic gaurds
- Do not operate near flammable substances
- Operate and Store between 20° and 100° F (-6° to 38°C)



Relay Input



Set
Screws



! WARNING
Read ALL
Instructions
Before Use

